


EN-ROUTE CHART-ICAO

FREE ROUTE AIRSPACE FL 245 TO FL 660



- FIR boundary
- CTA Sofia boundary
- SEE FRA boundary
- Arrival/ departure connecting route

FRA is available H24
 Decoding of FRA information:
 (I) - Intermediate point
 (A:****) - Arrival Connecting point and applicable aerodrome(s)
 (D:****) - Departure Connecting point and applicable aerodrome(s)
 (E:EVEN/ODD) - Horizontal Entry point and applicable cruising levels
 (X:EVEN/ODD) - Horizontal Exit point and applicable cruising levels
 Vertical relevance is indicated only where necessary as [Fnnn+/-] where
 "nnn" presents a FL
 "+" means 'at or above'
 "-" means 'at or below'

FRA DEPARTURE CONNECTING ROUTES

AIRPORT	SID last point	FRA Departure Connecting Route
LBBG	GONGO	GONGO L622 KOMAN / GONGO L622 EKSOL N605 AMTOV
	XILTI	XILTI L743 MATEL / XILTI Y189 RITAG / XILTI Q27 ARTAT
	ARNOV	ARNOV T226 ETUBA
LBWN	TOTKA	TOTKA N605 AMTOV
	DELIN	DELIN N605 GOL
LBGO	AMTOV	AMTOV N605 BODMO
	OGOTA	OGOTA N133 RESLA / OGOTA T228 BOBVO / OGOTA L615 DOLAP
LBSF	RUMEN	RUMEN N739 PDV P127 ROVDO
	VADEN*	VADEN N616 BAKLO
LTFM	TUDBU*	TUDBU Q26 ETUBA
	IBLAX*	IBLAX P727 BGS
LTFM, LTBA, LTFJ	MAKOL*	MAKOL N600 RORKI / MAKOL N617 BINBI

FRA ARRIVAL CONNECTING ROUTES

AIRPORT	STAR first point / IAF	FRA Arrival Connecting Route
LBBG	ESENA	RASUB [F245+] DCT BULEN L742 ESENA / BULEN [F245-] L742 ESENA / AMTOV N605 ALIVI L742 ESENA
	NESAR	MATEL T555 NESAR / RITAG Y189 NESAR / MAKOL L602 NESAR
LBWN	RUTAR	DINRO L919 GOSLO T228 RUTAR
	EXIGA	RASUB [F245+] DCT BULEN L744 EXIGA / BULEN [F245-] L744 EXIGA
	TUGSO	AMTOV N605 TUGSO
LBGO	TOTKA	AMTOV N605 TOTKA
	GOSLO	DINRO L919 GOSLO
LBSF	DELIN	GOL N605 DELIN
	AMTOV	BODMO N605 AMTOV
LTFM	RUMEN	ADUNO P92 PDV N739 RUMEN (Valid when TRA 63 is active)
	RILEX*	XANEX L606 GASRU T390 RILEX / SOPSIS T390 RILEX
LTFM, LTBA, LTFJ	AYTEK*	DEDIN DCT AYTEK / VELBA DCT AYTEK
	RIXEN*	BUVAK DCT RIXEN / MATEL N616 RIXEN

* See RAD for limitations on utilization of routes

INTENTIONALLY LEFT BLANK